

## GDR Tooth Build-Up Templates.



Properly maintaining demolition attachment teeth maximizes performance and optimizes the life of replacement parts. As teeth become worn, they need to be rotated, built-up or replaced.

To help customers determine and monitor how far processor teeth have worn from their original shape, Genesis has created tooth build-up templates.

Each template is sized and formed to that tooth's original shape and features three lines that indicate wear level. Simply place the template over the tooth to determine the amount of wear and build-up required or if replacement is needed.

Line 1	$\frac{1}{2}$ wear - schedule maintenance to flip or rotate in jaw	
Line 2	1" wear - flip, rotate in jaw or build up	
Line 3	1 <sup>1</sup> / <sub>2</sub> " wear - replace, if all points are worn on flippable teeth	

Contact your local Genesis dealer or the Genesis Parts Department to order.

Model	Part Number	Template
150 & 200	9100899	GENESIS
150 & 200	9102587	GIENIESUS GDR 150 / 200
300 & 400	9102826	GENESIS
300 & 400	9102586	GENESIS GDR 300/400



1000 Genesis Drive, Superior, WI 54880 888-SHEAR-IT (743-2748) – Tel: 715.395.5252 – genesisattachments.com Patents: genesisattachments.com/products/patents

